

DN-8468PB Data sheet

Version 2.1

For Panasonic minas A4 series Amplifier

1 DN-8468PB Daughter Board

The DN-8468PB is the daughter board for Panasonic A4 Series Amplifier. It has 4-axis I/O signals.

1.1 Board Layout for DN-8468PB




Fig. 1-1 Board layout for the DN-8468PB

1.2 Signal Connections for DN-8468PB

Maintaining signal connections is one of the most important factors in ensuring that your application system is sending and receiving data correctly.

■ Pin Assignment for CON1

The I/O connector on the DN-8468PB is a 68-pin SCSI II connector that enables you to connect to the I-8094 motion card. Fig. 1-2 shows the pin assignment for the 68-pin I/O connector on the DN-8468PB (or on the I-8094), and refer to Table 1-2, 1-3 for description of each motion I/O signal.




Fig. 1-2 I/O connector pin assignment for the CON1

Table 1-2 DN-8468PB I/O connector signal description (part 1)

| Pin name | Pin number | Description |
|----------|------------|--|
| XECA | 1 | Encoder A-phase signal for X axis |
| YECA | 36 | Encoder A-phase signal for Y axis |
| ZECA | 33 | Encoder A-phase signal for Z axis |
| UECA | 68 | Encoder A-phase signal for U axis |
| XECB | 2 | Encoder B-Phase signal for X axis |
| YECB | 37 | Encoder B-Phase signal for Y axis |
| ZECB | 32 | Encoder B-Phase signal for Z axis |
| UECB | 67 | Encoder B-Phase signal for U axis |
| XINPOS | 3 | In-position signal for X axis |
| YINPOS | 38 | In-position signal for Y axis |
| ZINPOS | 31 | In-position signal for Z axis |
| UINPOS | 66 | In-position signal for U axis |
| XALARM | 4 | Alarm signal for X axis |
| YALARM | 39 | Alarm signal for Y axis |
| ZALARM | 30 | Alarm signal for Z axis |
| UALARM | 65 | Alarm signal for U axis |
| XLMTM | 5 | Limit switch input signal (+) for X axis |
| YLMTM | 40 | Limit switch input signal (+) for Y axis |
| ZLMTM | 29 | Limit switch input signal (+) for Z axis |
| ULMTM | 64 | Limit switch input signal (+) for U axis |
| XLMTM | 6 | Limit switch input signal (-) for X axis |
| YLMTM | 41 | Limit switch input signal (-) for Y axis |
| ZLMTM | 28 | Limit switch input signal (-) for Z axis |
| ULMTM | 63 | Limit switch input signal (-) for U axis |
| XIN3 | 7 | Input 3 signal for X axis |
| YIN3 | 42 | Input 3 signal for Y axis |
| ZIN3 | 27 | Input 3 signal for Z axis |
| UIN3 | 62 | Input 3 signal for U axis |
| XIN2 | 8 | Input 2 signal for X axis |
| XIN2 | 43 | Input 2 signal for Y axis |
| XIN2 | 26 | Input 2 signal for Z axis |
| XIN2 | 61 | Input 2 signal for U axis |
| XIN1 | 9 | Input 1 signal for X axis |
| YIN1 | 44 | Input 1 signal for Y axis |
| ZIN1 | 25 | Input 1 signal for Z axis |
| UIN1 | 60 | Input 1 signal for U axis |
| XIN0 | 10 | Input 0 signal for X axis |
| YIN0 | 45 | Input 0 signal for Y axis |
| ZIN0 | 24 | Input 0 signal for Z axis |
| UIN0 | 59 | Input 0 signal for U axis |

Table 1-3 DN-8468PB I/O connector signal description (part 2)

| Pin name | Pin number | Description |
|----------|------------|--|
| XEXPP | 11 | EXT pulsar input signal (+) for X axis |
| YEXPP | 46 | EXT pulsar input signal (+) for Y axis |
| ZEXPP | 23 | EXT pulsar input signal (+) for Z axis |
| UEXPP | 58 | EXT pulsar input signal (+) for U axis |
| XEXPM | 12 | EXT pulsar input signal (-) for X axis |
| YEXPM | 47 | EXT pulsar input signal (-) for Y axis |
| ZEXPM | 22 | EXT pulsar input signal (-) for Z axis |
| UEXPM | 57 | EXT pulsar input signal (-) for U axis |
| XDRIVE | 13 | Driver enable signal for X axis |
| YDRIVE | 48 | Driver enable signal for Y axis |
| ZDRIVE | 21 | Driver enable signal for Z axis |
| UDRIVE | 56 | Driver enable signal for U axis |
| XPP | 14 | Driving pulsar signal (+) for X axis |
| YPP | 49 | Driving pulsar signal (+) for Y axis |
| ZPP | 20 | Driving pulsar signal (+) for Z axis |
| UPP | 55 | Driving pulsar signal (+) for U axis |
| XPM | 15 | Driving pulsar signal (+) for X axis |
| YPM | 50 | Driving pulsar signal (+) for Y axis |
| ZPM | 19 | Driving pulsar signal (+) for Z axis |
| UPM | 54 | Driving pulsar signal (+) for U axis |
| XOUT1 | 16 | Output 1 signal for X axis |
| YOUT1 | 48 | Output 1 signal for Y axis |
| ZOUT1 | 21 | Output 1 signal for Z axis |
| UOUT1 | 56 | Output 1 signal for U axis |
| EXPLSN1 | 17 | EXT pulse input signal for interpolation |
| EMGN1 | 52 | Emergency stop input signal |
| FRnetA | 16 | FRnet port A |
| FRnetB | 18 | FRnet port B |
| XDCC | 51 | Deviation Counter Clear for X axis |
| YDCC | 53 | Deviation Counter Clear for Y axis |
| GND | 34 | Ground |
| VCC | 35 | External power (12~24V) |

■ TB1

The connector TB1 is 7-pin connector that enables you to connect to the signals of your motor drivers. Fig.1-3 shows the pin assignment for the 7-pin connector on the DN-8468PB, and the Table 1-4 shows its I/O connector signal description.




Fig. 1-3 Pin definition for TB1

Table 1-4 TB1 Signal Connection

| Name | Description |
|---------|------------------------------------|
| FR-A | FRnet port A |
| FR-B | FRnet port B |
| DCC - X | Deviation Counter Clear for X axis |
| DCC - Y | Deviation Counter Clear for Y axis |
| E-PLS | EXT pulse signal |
| EMG-A | EMG input signal for all axes |
| E-GND | EXT power ground |

■ TB2

The connector TB2 is 5-pin connector that enables you to connect to the signals of your motor drivers. Fig.1-4 shows the pin assignment for the 5-pin connector on the DN-8468PB, and the Table 1-5 shows its I/O connector signal description.




Fig. 1-4 Pin definition for TB2

Table 1-5 TB2 Signal Connection

| Pin name | Description |
|----------|-----------------------|
| E-PWR | EXT power supply +24V |
| E-GND | EXT power ground |
| FGND | Frame ground |

► **Note:** Don't reverse connect signals with E_PWR and E_GND. Serious damage to your motion card and motion controller might be happened.

■ **CNX, CNY, CNZ, CNU (CN X5 connector for each AXIS in Driver)**

The connectors CNX, CNY, CNZ, and CNU are 50-pin connectors that enable you to connect to the CN X5 connector of Panasonic motor drivers. Fig.1-5 shows the pin assignment for the 50-pin connector on the DN-8468PB, and the Table 1-6 shows its I/O connector signal description.




Fig. 1-5 Pin definition for CNX, CNY, CNZ, CNU

Table 1-6 CN X5 Signal Connection

| Name | Number | Description |
|-------|---|------------------------------------|
| A+ | 21 | Encoder A-Phase (+) |
| A- | 22 | Encoder A-Phase (-) |
| B+ | 48 | Encoder B-Phase (+) |
| B- | 49 | Encoder B-Phase (-) |
| Z+ | 23 | Encoder Z-Phase (+) |
| Z- | 24 | Encoder Z-Phase (-) |
| P+ | 4 | Positive Direction Pulse Output(+) |
| P- | 3 | Positive Direction Pulse Output(-) |
| N+ | 6 | Negative Direction Pulse |
| N- | 5 | Negative Direction Pulse Output(-) |
| INP | 39 | Servo In Position |
| RDY | 35 | Servo Ready |
| SVON | 29 | Servo On |
| A-CLR | 31 | Alarm Clear |
| ALARM | 37 | Servo Alarm |
| E-PWR | 7 | EXT power +24V |
| E-GND | 8, 9, 13, 15,17, 25, 33,34, 36, 38,41 | EXT power ground |
| NC | 1,2,10,11, 12,14,16, 18,19,20, 26,27,28, 30,32,40, 42,43,44, 45,46,47, 50 | No connection |

- ▶ **Note 1:** There are two sets encoder signals for X and Y axes. In X axis, one is from CNX and the other is from CN5. In Y axis, one is from CNY and the other is from CN6. Users can select encoder signals from JP1 and JP2, respectively.
- ▶ **Note 2:** In Z and U axes, only one set of encoder signals is used for each axis. In Z axis, do not connect CNZ and CN7 at the same time. In U axis, do not connect CNU and CN8 at the same time.
- ▶ **Note 3 :** Don't connect NC (not connected) signals. Connecting these signals could cause permanent damage to your motion controller.

■ **CN1~CN4 (The I/O signals of the X, Y, Z, U AXIS)**

The connectors CN1~CN4 are 11-pin connectors that enable you to connect to the signals of your motor drivers. Fig.1-7 shows the pin assignment for the 20-pin connector on the DN-8468PB, and the Table 1-8 shows its I/O connector signal description.




Fig.1-7 Pin definition for CN1 ~ CN4

Table 3-8 CN1~4 Signal Connection

| Pin name | Description |
|----------|----------------------------------|
| E-PWR | EXT power supply +24V |
| EMG | EMG input signal |
| LMT+ | Limit Switch Input Signal (+) |
| LMT- | Limit Switch Input Signal (-) |
| INPUT3 | Input Signal (IN3) |
| NRHOME | Near Home Sensor Input Signal |
| HOME | Home Sensor Input Signal |
| RESET | Reset input signal |
| EXP+ | EXT Positive Direction Pulse (+) |
| EXP- | EXT Negative Direction Pulse (-) |
| E-GND | EXT power ground |

■ CN5~CN8 (The I/O signals of the X, Y, Z, U AXIS)

The connectors CN5~CN8 are 15-pin connectors that enable users to connect the signals to external motor drivers. Fig.1-8 shows the pin assignment for the 15-pin connector on the DN-8468PB, and the Table 1-9 shows its I/O connector signal description.




Fig. 1-8 Pin definition for CN5 ~ CN8

Table 1-9 CN5~8

| Name | No. | Description |
|--------|-----------|------------------------------------|
| A+ | 9 | Encoder A-Phase (+) |
| A- | 4 | Encoder A-Phase (-) |
| B+ | 10 | Encoder B-Phase (+) |
| B- | 5 | Encoder B-Phase (-) |
| Z+ | 11 | Encoder Z-Phase (+) |
| Z- | 12 | Encoder Z-Phase (-) |
| P+ | 1 | Positive Direction Pulse Output(+) |
| P- | 7 | Positive Direction Pulse Output(-) |
| N+ | 2 | Negative Direction Pulse Output(+) |
| N- | 8 | Negative Direction Pulse Output(-) |
| E-PWR | 15 | EXT power +24V |
| E-GND | 3 | EXT power ground |
| EXT-5V | 6 | EXT power +5V |
| NC | 13, 14 | No connection |

- ▶ **Note 1:** There are two sets encoder signals for X and Y axes. In X axis, one is from CNX and the other is from CN5. In Y axis, one is from CNY and the other is from CN6. Users can select encoder signals from JP1 and JP2, respectively.
- ▶ **Note 2:** In Z and U axes, only one set of encoder signals is used for each axis. In Z axis, do not connect CNZ and CN7 at the same time. In U axis, do not connect CNU and CN8 at the same time.
- ▶ **Note 3 :** Don't connect NC (not connected) signals. Connecting these signals could cause permanent damage to your motion controller.

■ RJ1 (The I/O signals of the FRnet)

The connectors RJ1 is an 8-pin RJ45 connector that enable you to connect to the signals of FRnet. Fig.1-9 shows the pin assignment for the 8-pin connector on the DN-8468PB, and the Table 1-10 shows its I/O connector signal description.




Table 1-10 RJ1

| Pin name | Description |
|----------|---------------|
| FRnetA | FRnet port A |
| FRnetB | FRnet port B |
| NC | No connection |

Fig. 1-9 Pin definition for RJ1

▶ **Note:** Don't connect NC (not connected) signals. Connecting these signals could cause permanent damage to your motion controller.

1.3 Jumper and Switch Settings

■ JP5

Jumper 5 controls the EMG-A signal of the TB1 connector. The following diagram is shown the selection condition of the jumper 5.




Fig. 1-10 Jumper 5 setting

■ JP1, JP2

The encoder signals of axis X and axis Y can be chosen from servo driver encoder or external encoder. Fig. 1-11 shows that the encoder signals are selected from servo driver encoder. In meantime, Fig. 1-12 shows that the encoder signals are selected from external encoder.




Fig. 1-11 Primary encoder signals setting




Fig. 1-12 External encoder signals setting

■ EMG SW

The emergency stop signal for each servo amplifier can be selected from EMG SW. The number 1, 2, 3, 4 on EMG SW are denoted as axis X, Y, Z, U, respectively. Fig. 1-13 is the default setting to connect the EMG signals to GND. The EMG signals from CN1 ~ CN4 will not take effect. If the switch is disconnected as shown in Fig. 1-14, the emergency stop signals can be controlled from EMG signals in CN1 ~ CN4.




Fig. 1-13 EMG SW setting for normally GND (Default setting)




Fig. 1-14 EMG SW setting for user controlled signals.